



XP-3179-S v. 2.1b

---

# Installation

## XP-BLY6803

---

— **Installation Time:** About 20 minutes

— **Tools Required:** 1/4" Nut-driver, Phillips screwdriver

1. Unplug the AC power from your pinball machine. Remove game backglass. Unplug all display board connecting cables and remove the 2 original glass display circuit boards.
2. Mount both new boards in the backbox. The boards are identical and interchangeable for left or right side mounting. If not already in place, attach the foam light shields on their respective LED displays.
3. Connect the cables.
4. Double-check all connections, plug in the machine, and turn the game on. The LEDs will light up. Pressing the **DIAGNOSTIC** pushbutton on the XP-BLY6803-P boards will illuminate all segments of all displays. This indicates that all boards and cables in the XPin™ System are operating correctly. Use the thumbwheel **BRIGHTNESS** control on the board to set your preferred illumination level.
5. PLAY PINBALL! You'll enjoy your XPin™ displays for years to come!



---

# Installation

[XPinPinball.com](http://XPinPinball.com)

[tech@XPinPinball.com](mailto:tech@XPinPinball.com)